

# Technical Bulletin


## Web Interface Firmware Update Instructions

AN-300-RT-4L2W Network Router



## Instructions

This document details how to update your Araknis device firmware using the web interface. To upgrade using OvrC, access your OvrC account and find the instructions there (<https://app.ovrc.com/#/login>).



1. Log into the device's web interface. Default access:
  - **IP Address** – 192.168.1.1
  - **Username** – araknis
  - **Password** – araknis
2. Click **File Management** in the left menu to get to the firmware update menu.
3. Click the **Choose File** button under the **Firmware** submenu and navigate to where the firmware file is saved on your computer.
4. Select the file and then press **Enter/Return** on the computer keyboard or click **Open** on the menu. (The firmware file name should appear next to the Upload New Firmware File **Browse** button.)
5. Click **Upload**. The Upload Firmware Information screen will open.
6. Click **Upgrade**. Wait while the new firmware loads.
7. Refresh the page after the update is complete.
8. Enter the username and password.
9. Confirm the new firmware version is installed.

## Contacting Technical Support

Phone: (866) 838-5052

Email: [support@araknisnetworks.com](mailto:support@araknisnetworks.com)