

**CONTACTING TECH SUPPORT**

Phone: (866) 838-5052 (704) 909-5229

Email: TechSupport@SnapAV.com

**CHANGES IN THIS RELEASE**

**v1.1**  
Added Input Summing option to the HTTP driver properties. Disabled will result in all other inputs being dropped when selecting a new input/output mapping.

- V1.2**
- Added configurable poll interval to the HTTP driver properties. Default poll interval is 30 seconds.
  - Fixed input and output matrix to show 2x4.
  - Added proxy notification for active input for each output.