

Dragonfly™ Fixed Projection Screen Material Installation Guide



1. Assemble the screen frame according to the instructions in the screen manual, then lay it face down on a clean, flat surface.
2. Wash your hands and clean the work area to avoid staining the screen material.
3. Unpack the screen material and tension rods.
4. Unroll the screen material and lay it flat, with the seam side up, across the back of the screen frame.
5. Push the shorter tension rods through the edges of the screen material, making sure not to damage the material. Do not insert the longer rods yet.
6. Attach snaps 1-4 in order.
7. Insert the longer tension rods.
8. Attach snaps 5-8 in order.
9. Working from the outside towards the center:
 - a. Attach the remaining snaps on the short sides, 9 and 10 last.
 - b. Attach the remaining snaps on the long sides, 11 and 12 last.

