



Observe proper assembly order during termination:

- 1) Strip cable jacket to expose 1" of wire strands.
- 2) Install twist separator (C).
- 3) Separate and order conductors per TIA/EIA 568-A/B.
- 4) Slide load bar (B) over conductors and separator.
- 5) Cut conductors flush with the end of the load bar.
- 6) Insert cable assembly into connector.
- 7) Terminate using a suitable RJ45 crimping tool.