



INSTALLATION INSTRUCTIONS

1. Tape this template to the drywall  
Center the template between two studs. Make sure that it's 14.25" W x 11" H
2. Mark the Location of the holes.  
Use a punch or screw to mark holes in each corner.
3. Remove the template and drill the holes  
Use an 1/8" or smaller bit, drill through all the holes marked in previous step.
4. Cut the drywall opening  
Use a drywall saw to cut between the holes drilled.

Cutout Dimensions - 14.25" W x 11" H

THIS MUST BE PRINTED ON A 17" W x 22" H SHEET OF PAPER AT A 1:1 RATIO!