

**SM-RBX-14-WH** | Cutout Template



**INSTALLATION INSTRUCTIONS**

- 1. Tape this template to the drywall**  
Center the template between two studs. Make sure that it's 14" W x 13 1/4" H
- 2. Mark the Location of the holes.**  
Use a punch or screw to mark holes in each corner.
- 3. Remove the template and drill the holes**  
Use an 1/8" or smaller bit, drill through all the holes marked in previous step.
- 4. Cut the drywall opening**  
Use a drywall saw to cut between the holes drilled.

**Cutout Dimensions - 14" W x 13 1/4" H**

**THIS MUST BE PRINTED ON A 17" W x 22" H SHEET OF PAPER AT A 1:1 RATIO!**