



Episode Extreme Speakers DSP Settings Guide

		EQ1	EQ2	EQ3	EQ4	EQ5	EQ6	EQ7	EQ8	EQ9	EQ10	EQ11	EQ12
ES-XTR-6-IC	Type	High Pass	High Shelf	Peaking	Peaking	Peaking	Peaking	High Shelf	Not Used	Peaking	High Shelf	Not Used	Not Used
	Order	2nd (12dB)	1st	2nd	2nd	2nd							
	Frequency	80	3000	90	155	1600							
	Gain	0	3	8	-6	2							
	Q	0.707	0.707	2.0	2.5	0.707							
ES-XTR-8-IC	Type	High Pass	High Shelf	Peaking	Peaking	Peaking	Peaking	Not Used	Not Used	Not Used	Not Used	Not Used	Not Used
	Order	2nd (12dB)	1st	2nd	2nd	2nd	2nd						
	Frequency	70	3000	85	120	300	4200						
	Gain	0	2	6	-4	2.5	3						
	Q	0.707	0.707	1.2	2.5	2	2						