

YXC Function List (Ver.1.40)

Based on YXC API Specification(Basic) Ver.2.10 / YXC API Specification(Advanced) Ver.2.10

Function	Remark	Model Name					
		Vx85(OSD)	Vx85(GUI)	WX-051 WX-021	YAS-706 YMS-4080	TT-N503	XDA- QS5400
System							
	Network Connection	wired, wireless	✓	✓	✓	✓	✓
	IP Setting		✓	✓	✓	✓	✓
	Edit Friendly Name		✓	✓	✓	✓	✓
	Airplay Password		✓	✓	✓	✓	✓
	MAC Address Filter		✓	✓	✓	✓	✓
	Network Standby	on, off	✓	✓	✓	✓	✓
	Bluetooth Standby	on, off	✓	✓	✓	✓	—
	Bluetooth Transmitter	on, off	✓	✓	✓	✓	—
	Speaker A/B		—	—	—	—	—
	Dimmer		—	—	—	—	—
	Zone B Volume Sync		✓	—	—	—	—
	HDMI OUT Setting	HDMI OUT 1/2/3	✓	—	—	—	—
	Auto Power Standby	on, off	✓	✓	✓	✓	—
	Send IR Code		✓	—	✓	—	✓
	System Reboot		✓	✓	✓	✓	✓
	Auto Play	on, off	—	—	—	✓	—
	Speaker Pattern		—	✓	—	—	—
	Party Mode	on, off	—	✓	—	—	—
	Stereo Pair		—	—	—	—	—
	MusicCast Surround/Stereo		✓	✓	✓	—	—
Zone							
	Power		✓	✓	✓	✓	✓
	Sleep		✓	✓	✓	✓	✓
	Volume		✓	✓	✓	✓	✓
	Mute		✓	✓	✓	✓	✓
	Select Input		✓	✓	✓	✓	✓
	Select Sound Program		✓	✓	✓	—	—
	3D surround		—	—	✓	—	—
	Surround AI		—	✓	—	—	—
	Pure Direct / Direct		✓	✓	—	—	—
	Enhancer		✓	✓	—	—	✓
	Tone Control		✓	✓	—	—	—
	Equalizer		—	—	✓	—	✓
	Balance		—	—	—	—	—
	Dialogue Level		✓	✓	—	—	—
	Dialogue Lift		—	—	—	—	—
	Clear Voice		—	—	✓	—	—
	Subwoofer Volume		—	—	✓	—	—
	Bass Extension		—	—	✓	—	✓
	Recall Scene		✓	✓	—	—	—
	Contents Display		✓	✓	—	—	—
	Control Cursor		✓	✓	—	—	—
	Control Menu		✓	✓	—	—	—
	Actual Volume		✓	✓	—	—	—
	Audio Select		✓	✓	—	—	—
	Surround Decoder Type		✓	✓	—	—	—
	Link Control	speed, standard, stability	✓	✓	✓	✓	✓
	Link Audio Delay		✓	✓	—	✓	✓
Tuner							
	Preset	add, select, clear	✓	✓	—	—	—
	auto preset		—	—	—	—	—
	PlayControl		✓	✓	—	—	—
	Band select	FM/ AM /DAB	✓	✓	—	—	—
	Tuning	Plus / Minus / Auto	✓	✓	—	—	—
	Play Information	Freq, RDS, Station name(DAB), DLS(DAB)	✓	✓	—	—	—
	DAB Initial Scan		—	—	—	—	—
	DAB TuneAid		—	—	—	—	—
Network							
	ListBrowse		✓	✓	✓	✓	✓
	Preset	add, select, clear	✓	✓	✓	✓	✓
	Play Control	Play, Pause, Stop, Skip +/-	✓	✓	✓	✓	✓
	Play Information	Coverart, Album, Song, Artist	✓	✓	✓	✓	✓
	Repeat		✓	✓	✓	✓	✓
	Shuffle		✓	✓	✓	✓	✓
	Time Seek		✓	✓	✓	✓	✓
	Time Counter		✓	✓	✓	✓	✓
USB							
	ListBrowse		✓	✓	—	—	✓
	Preset	add, select, clear	✓	✓	—	—	✓
	Play Control	Play, Pause, Stop, Skip +/-	✓	✓	—	—	✓
	Play Information	Coverart, Album, Song, Artist	✓	✓	—	—	✓
	Repeat		✓	✓	—	—	✓
	Shuffle		✓	✓	—	—	✓
	Time Seek		—	—	—	—	—
	Time Counter		✓	✓	—	—	✓
CD							
	ListBrowse		—	—	—	—	—
	PlayControl		—	—	—	—	—
	Play Information	track no, Album, Song, Artist (when meta-information of data CD is retrieved)	—	—	—	—	—
	TrayControl	open / close	—	—	—	—	—
	Repeat		—	—	—	—	—
	Shuffle		—	—	—	—	—
	Time Seek		—	—	—	—	—
	Time Counter		—	—	—	—	—
Clock							
	Adjust Clock (Auto)		—	—	✓	—	—
	Enable		—	—	✓	—	—
	Repeat		—	—	✓	—	—
	Time		—	—	✓	—	—
	Volume		—	—	✓	—	—
	Source		—	—	✓	—	—
	Source Detail		—	—	✓	—	—
	Type		—	—	✓	—	—
Turn Table							
	Rotation Time		—	—	—	✓	—
Distribution							
	Distribution		✓	✓	✓	✓	✓

Vx85(OSD): RX-V485, HTR-4072, RX-D485, RX-V585, HTR-5072, TSR-5850, RX-A680, RX-S602

Vx85(GUI): RX-V685, RX-A780, RX-A880, RX-A1080, RX-V1085, RX-A2080, RX-V2085, RX-A3080, RX-V3085
CX-A5200

YXC Function List (Ver.1.40)

Based on YXC API Specification(Basic) Ver.2.10 / YXC API Specification(Advanced) Ver.2.10

Function		Remark	Model Name				
System			Vx83(OSD)	Vx83(GUI)	R-N803/D	R-N303/D	NP-S303
	Network Connection	wired, wireless	✓	✓	✓	✓	✓
	IP Setting		✓	✓	✓	✓	✓
	Edit Friendly Name		✓	✓	✓	✓	✓
	Airplay Password		✓	✓	✓	✓	✓
	MAC Address Filter		✓	✓	✓	✓	✓
	Network Standby	on, off	✓	✓	✓	✓	✓
	Bluetooth Standby	on, off	✓	✓	✓	✓	✓
	Bluetooth Transmitter	on, off	✓	✓	✓	✓	✓
	Speaker A/B		—	—	✓	✓	—
	Dimmer		—	—	—	—	—
	Zone B Volume Sync		✓	—	—	—	—
	HDMI OUT Setting	HDMI OUT 1/2/3	✓	✓	—	—	—
	Auto Power Standby	on, off	—	—	✓	✓	✓
	Send IR Code		✓	✓	✓	✓	✓
	System Reboot		✓	✓	✓	✓	✓
	Auto Play	on, off	—	—	—	—	—
	Speaker Pattern		—	✓	—	—	—
	Party Mode	on, off	—	✓	—	—	—
	Stereo Pair		—	—	—	—	—
	MusicCast Surround/Stereo		—	—	—	—	—
Zone							
	Power		✓	✓	✓	✓	✓
	Sleep		✓	✓	—	—	—
	Volume		✓	✓	✓	✓	—
	Mute		✓	✓	✓	✓	—
	Select Input		✓	✓	✓	✓	✓
	Select Sound Program		✓	✓	—	—	—
	3D surround		—	—	—	—	—
	Surround AI		—	—	—	—	—
	Pure Direct / Direct		✓	✓	—	—	—
	Enhancer		✓	✓	—	—	—
	Tone Control		✓	✓	—	✓	—
	Equalizer		—	—	—	—	—
	Balance		—	—	—	✓	—
	Dialogue Level		✓	✓	—	—	—
	Dialogue Lift		—	—	—	—	—
	Clear Voice		—	—	—	—	—
	Subwoofer Volume		—	—	—	—	—
	Bass Extension		—	—	—	—	—
	Recall Scene		✓	✓	—	—	—
	Contents Display		✓	✓	—	—	—
	Control Cursor		✓	✓	—	—	—
	Control Menu		✓	✓	—	—	—
	Actual Volume		✓	✓	—	—	—
	Audio Select		✓	✓	—	—	—
	Surround Decoder Type		✓	✓	—	—	—
	Link Control	speed, standard, stability	✓	✓	✓	✓	✓
	Link Audio Delay		✓	✓	—	—	—
Tuner							
	Preset	add, select, clear	✓	✓	✓	✓	—
	auto preset		—	—	—	—	—
	PlayControl		✓	✓	✓	✓	—
	Band select	FM/ AM /DAB	✓	✓	✓	✓	—
	Tuning	Plus / Minus / Auto	✓	✓	✓	✓	—
	Play Information	Freq, RDS, Station name(DAB), DLS(DAB)	✓	✓	✓	✓	—
	DAB Initial Scan		—	—	—	—	—
	DAB TuneAid		—	—	—	—	—
Network							
	ListBrowse		✓	✓	✓	✓	✓
	Preset	add, select, clear	✓	✓	✓	✓	✓
	Play Control	Play, Pause, Stop, Skip +/-	✓	✓	✓	✓	✓
	Play Information	Coverart, Album, Song, Artist	✓	✓	✓	✓	✓
	Repeat		✓	✓	✓	✓	✓
	Shuffle		✓	✓	✓	✓	✓
	Time Seek (DLNA)		✓	✓	✓	✓	✓
	Time Counter		✓	✓	✓	✓	✓
USB							
	ListBrowse		✓	✓	✓	—	✓
	Preset	add, select, clear	✓	✓	✓	—	✓
	Play Control	Play, Pause, Stop, Skip +/-	✓	✓	✓	—	✓
	Play Information	Coverart, Album, Song, Artist	✓	✓	✓	—	✓
	Repeat		✓	✓	✓	—	✓
	Shuffle		✓	✓	✓	—	✓
	Time Seek		—	—	—	—	—
	Time Counter		✓	✓	✓	—	✓
CD							
	ListBrowse		—	—	—	—	—
	PlayControl		—	—	—	—	—
	Play Information	track no, Album, Song, Artist (when meta-information of data CD is retrieved)	—	—	—	—	—
	TrayControl	open / close	—	—	—	—	—
	Repeat		—	—	—	—	—
	Shuffle		—	—	—	—	—
	Time Seek		—	—	—	—	—
	Time Counter		—	—	—	—	—
Clock							
	Adjust Clock (Auto)		—	—	—	—	—
	Enable		—	—	—	—	—
	Repeat		—	—	—	—	—
	Time		—	—	—	—	—
	Volume		—	—	—	—	—
	Source		—	—	—	—	—
	Source Detail		—	—	—	—	—
	Type		—	—	—	—	—
Turn Table							
	Rotation Time		—	—	—	—	—
Distribution							
	Distribution		✓	✓	✓	✓	✓

Vx83(OSD): RX-V483, HTR-4071, RX-V583, HTR-5071, TSR-5830, RX-A670

Vx83(GUI) : RX-V683, RX-A770, RX-A870, RX-A1070, RX-V1083, RX-A2070, RX-V2083, RX-A3070, RX-V3083

YXC Function List (Ver.1.40)

Based on YXC API Specification(Basic) Ver.2.10 / YXC API Specification(Advanced) Ver.2.10

Function			Remark		Model Name							
			Vx81(OSD)	Vx81(GUD)	WXA-50 WXC-50	R-N402/D	CRX-N470/D	ISX-18/D	WX-010	YAS-306	YAS-706	YSP-2700
System	Network Connection	wired, wireless	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	IP Setting		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Edit Friendly Name		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Airplay Password		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	MAC Address Filter		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Network Standby	on, off	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Bluetooth Standby	on, off	✓	✓	✓	✓	—	—	—	—	—	—
	Bluetooth Transmitter	on, off	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Speaker A/B		—	—	✓	—	—	—	—	—	—	—
	Dimmer		—	—	—	—	—	—	—	—	—	—
	Zone B Volume Sync		✓	—	—	—	—	—	—	—	—	—
	HDMI OUT Setting	HDMI OUT 1/2/3	✓	✓	—	—	—	—	—	—	—	—
	Auto Power Standby	on, off	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Send IR Code		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	System Reboot		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Auto Play	on, off	—	—	—	—	—	—	—	—	—	—
	Speaker Pattern		—	✓	—	—	—	—	—	—	—	—
	Party Mode	on, off	—	✓	—	—	—	—	—	—	—	—
	Stereo Pair		—	—	—	—	—	✓	—	—	—	—
	MusicCast Surround/Stereo		—	—	—	—	—	—	—	—	—	—
Zone	Power		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Sleep		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Volume		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Mute		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Select Input		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Select Sound Program		✓	✓	—	—	—	—	✓	✓	✓	✓
	3D surround		—	—	—	—	—	—	—	—	—	—
	Surround AI		—	—	—	—	—	—	—	—	—	—
	Pure Direct / Direct		✓	✓	✓	—	—	—	—	—	—	—
	Enhancer		✓	✓	✓	—	—	—	—	—	—	✓
	Tone Control		✓	✓	✓	✓	✓	—	—	—	—	✓
	Equalizer		—	—	—	✓	—	✓	—	—	—	—
	Balance		—	—	✓	—	—	—	—	—	—	—
	Dialogue Level		✓	✓	—	—	—	—	—	—	—	—
	Dialogue Lift		—	—	—	—	—	—	—	—	—	—
	Clear Voice		—	—	—	—	—	—	✓	—	✓	—
	Subwoofer Volume		—	—	✓	—	—	—	✓	—	✓	✓
	Bass Extension		—	—	✓	—	—	—	—	✓	—	—
	Recall Scene		✓	✓	—	—	—	—	—	—	—	—
	Contents Display		✓	✓	—	—	—	—	—	—	—	—
	Control Cursor		✓	✓	—	—	—	—	—	—	—	—
	Control Menu		✓	✓	—	—	—	—	—	—	—	—
	Actual Volume		✓	✓	✓	—	—	—	—	—	—	—
	Audio Select		✓	✓	—	—	—	—	—	—	—	—
	Surround Decoder Type		✓	✓	—	—	—	—	—	—	—	—
	Link Control	speed, standard, stability	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Link Audio Delay		✓	✓	✓	—	—	—	—	—	—	—
Tuner	Preset	add, select, clear	✓	✓	—	✓	✓	✓	—	—	—	—
	auto preset		—	—	—	—	—	✓	—	—	—	—
	PlayControl		✓	✓	✓	✓	✓	✓	—	—	—	—
	Band select	FM/ AM /DAB	✓	✓	—	—	✓	✓	—	—	—	—
	Tuning	Plus / Minus / Auto	✓	✓	—	—	✓	✓	—	—	—	—
	Play Information	Freq, RDS, Station name(DAB, DLS/DAB)	✓	✓	—	—	✓	✓	—	—	—	—
	DAB Initial Scan		—	—	—	—	—	✓	—	—	—	—
	DAB TuneAd		—	—	—	—	—	—	—	—	—	—
	Network/USB		—	—	—	—	—	—	—	—	—	—
	ListBrowse		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
CD	Preset	add, select, clear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Play Control	Play, Pause, Stop, Skip +/-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Play Information	Coverart, Album, Song, Artist	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Repeat		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Shuffle		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Time Seek (DLNA)		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Time Counter		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
			—	—	—	—	—	—	—	—	—	—
	ListBrowse		—	—	—	—	✓	—	—	—	—	—
	PlayControl		—	—	—	—	—	—	—	—	—	—
Clock	Play Information	track no, Album, Song, Artist (when meta-information of data CD is retrieved)	—	—	—	—	✓	—	—	—	—	—
	TrayControl	open / close	—	—	—	—	✓	—	—	—	—	—
	Repeat		—	—	—	—	✓	—	—	—	—	—
	Shuffle		—	—	—	—	✓	—	—	—	—	—
	Time Seek		—	—	—	—	✓	—	—	—	—	—
	Time Counter		—	—	—	—	✓	—	—	—	—	—
			—	—	—	—	—	—	—	—	—	—
	Adjust Clock (Auto)		—	—	—	—	—	✓	—	—	—	—
	Enable		—	—	—	—	—	✓	—	—	—	—
	Repeat		—	—	—	—	—	✓	—	—	—	—
Turn Table	Time		—	—	—	—	—	✓	—	—	—	—
	Volume		—	—	—	—	—	✓	—	—	—	—
	Source		—	—	—	—	—	✓	—	—	—	—
	Source Detail		—	—	—	—	—	✓	—	—	—	—
	Type		—	—	—	—	—	✓	—	—	—	—
			—	—	—	—	—	—	—	—	—	—
	Rotation Time		—	—	—	—	—	—	—	—	—	—
			—	—	—	—	—	—	—	—	—	—
	Distribution		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
			—	—	—	—	—	—	—	—	—	—

Vx81(OSD): RX-V481, RX-V481D, RX-V581, RX-A660, HTR-4069, HTR-5069, TSR-5810

Vx81(GUD): RX-V681, RX-A760, RX-V781, RX-A860, RX-A1060, RX-V1081, RX-A2060, RX-V2081, RX-A3060, RX-V3081
TSR-7810

YXC Function List (Ver.1.40)

Based on YXC API Specification(Basic) Ver.2.10 / YXC API Specification(Advanced) Ver.2.10

Function		Remark	Model Name									
System			Vx79(OSD)	Vx79(GUD)	R-N602	NX-N500	CD-NT670/D	ISX-80	WX-030	SRT-1500	YSP-1600	YSP-5600
System	Network Connection	wired, wireless	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	IP Setting		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Edit Friendly Name		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Airplay Password		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	MAC Address Filter		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Network Standby	on, off	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Bluetooth Standby	on, off	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Bluetooth Transmitter	on, off	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Speaker A/B		—	—	✓	—	—	—	—	—	—	—
	Dimmer		—	—	—	✓	—	—	—	—	—	—
	Zone B Volume Sync		✓	—	—	—	—	—	—	—	—	—
	HDMI OUT Setting	HDMI OUT 1/2/3	✓	✓	—	—	—	—	—	—	—	—
	Auto Power Standby	on, off	—	—	✓	✓	—	✓	✓	✓	✓	✓
	Send IR Code		✓	✓	✓	✓	—	✓	✓	✓	✓	✓
	System Reboot		✓	✓	✓	—	✓	✓	✓	✓	✓	✓
	Auto Play	on, off	—	—	—	—	—	—	—	—	—	—
	Speaker Pattern		—	✓	—	—	—	—	—	—	—	—
	Party Mode	on, off	—	✓	—	—	—	—	—	—	—	—
	Stereo Pair		—	—	—	—	—	—	✓	—	—	—
	MusicCast Surround/Stereo		—	—	—	—	—	—	—	—	—	—
Zone	Power		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Sleep		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Volume		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Mute		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Select Input		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Select Sound Program		✓	✓	✓	—	—	—	—	✓	✓	✓
	3D surround		—	—	—	—	—	—	—	—	—	✓
	Surround AI		—	—	—	—	—	—	—	—	—	—
	Pure Direct / Direct		✓	✓	—	—	—	—	—	—	—	—
	Enhancer		✓	✓	—	✓	—	—	—	—	—	—
	Tone Control		✓	✓	—	✓	—	—	—	—	—	✓
	Equalizer		—	—	—	—	—	✓	✓	—	—	—
	Balance		—	—	—	✓	—	—	—	—	—	—
	Dialogue Level		—	✓	—	—	—	—	—	—	—	—
	Dialogue Lift		—	—	—	—	—	—	—	—	—	✓
	Clear Voice		—	—	—	—	—	—	—	✓	✓	✓
	Subwoofer Volume		—	—	—	—	—	—	—	✓	✓	✓
	Bass Extension		—	—	—	—	—	—	—	✓	✓	✓
	Recall Scene		✓	✓	—	—	—	—	—	—	—	—
	Contents Display		✓	✓	—	—	—	—	—	—	—	—
Tuner	Control Cursor		✓	✓	—	—	—	—	—	—	—	—
	Control Menu		✓	✓	—	—	—	—	—	—	—	—
	Actual Volume		✓	✓	—	—	—	—	—	—	—	—
	Audio Select		✓	✓	—	—	—	—	—	—	—	—
	Surround Decoder Type		✓	✓	—	—	—	—	—	—	—	—
	Link Control	speed, standard, stability	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Link Audio Delay		✓	✓	—	—	—	—	—	✓	—	—
	Preset	add, select, clear	✓	✓	✓	—	✓	✓	—	—	—	—
	auto preset		—	—	—	—	—	—	—	—	—	—
	PlayControl		✓	✓	✓	—	✓	✓	—	—	—	—
	Band select	FM/ AM /DAB	✓	✓	✓	—	✓	✓	—	—	—	—
	Tuning	Plus / Minus / Auto	✓	✓	✓	—	✓	✓	—	—	—	—
	Play Information	Freq, RDS, Station name(DAB), DLS(DAB)	✓	✓	✓	—	✓	✓	—	—	—	—
	DAB Initial Scan		—	—	—	—	—	—	—	—	—	—
	DAB TuneAid		—	—	—	—	—	—	—	—	—	—
Network/USB	ListBrowse		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Preset	add, select	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Play Control	Play, Pause, Stop, Skip +/-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Play Information	Coverart, Album, Song, Artist	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Repeat		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Shuffle		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Time Seek (DLNA)		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	Time Counter		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	ListBrowse		—	—	—	—	✓	—	—	—	—	—
	PlayControl		—	—	—	—	—	—	—	—	—	—
CD	Play Information	track no, Album, Song, Artist (when meta-information of data CD is retrieved)	—	—	—	—	✓	—	—	—	—	—
	TrayControl	open / close	—	—	—	—	✓	—	—	—	—	—
	Repeat		—	—	—	—	✓	—	—	—	—	—
	Shuffle		—	—	—	—	✓	—	—	—	—	—
	Time Seek		—	—	—	—	✓	—	—	—	—	—
	Time Counter		—	—	—	—	✓	—	—	—	—	—
	Clock		—	—	—	—	—	—	—	—	—	—
Clock	Adjust Clock (Auto)		—	—	—	—	—	✓	—	—	—	—
	Enable		—	—	—	—	—	✓	—	—	—	—
	Repeat		—	—	—	—	—	✓	—	—	—	—
	Time		—	—	—	—	—	✓	—	—	—	—
	Volume		—	—	—	—	—	✓	—	—	—	—
	Source		—	—	—	—	—	✓	—	—	—	—
	Source Detail		—	—	—	—	—	✓	—	—	—	—
Turn Table	Type		—	—	—	—	—	✓	—	—	—	—
	Rotation Time		—	—	—	—	—	—	—	—	—	—
Distribution												
	Distribution		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Vx79(OSD) : RX-V479, RX-V579, RX-A550, HTR-4068, TSR-5790, RX-S601, RX-S601D

Vx79(GUD) : RX-V679, RX-A750, RX-V779, RX-A850, RX-A1050, RX-V1079, RX-A2050, RX-V2079, RX-A3050, RX-V3079
HTR-6068, TSR-7790, RX-AS710, RX-AS710D
CX-A5100