

Yamaha Extended IR codes for WXA-50, WXC-50

*A: Australia model, B and G: Europe model, C: Canada model, U: USA model

*T: China model, J: Japan model, K: Korea model

rev 0

Function			Device		Code (ID1)	Code (ID2)	WXA-50 WXC-50		
Group	Name			Zone					
POWER	POWER	ON	RECEIVER	MAIN	7E-7E	7E-7E80	YES		
	STANDBY	OFF	RECEIVER	MAIN	7E-7F	7E-7F81	YES		
	SLEEP	ON	RECEIVER	MAIN	7E-1669	7E-1668	YES		
		OFF	RECEIVER	MAIN	7E-1B64	7E-1B65	YES		
		120min	RECEIVER	ALL	7E-B4	7E-B44A	YES		
		90min	RECEIVER	ALL	7E-B5	7E-B54B	YES		
		60min	RECEIVER	ALL	7E-B6	7E-B648	YES		
		30min	RECEIVER	ALL	7E-B7	7E-B749	YES		
INPUT	SUB INPUT	SERVER	RECEIVER	MAIN	7F01-6C13	7F01-6C12	YES		
		NET RADIO	RECEIVER	MAIN	7F01-6F10	7F01-6F11	YES		
		Rhapsody or Napster	RECEIVER	MAIN	7F01-750A	7F01-750B	YES		
		Pandora *UA	RECEIVER	MAIN	7F01-85FA	7F01-85FB	YES		
		SiriusXM *UC	RECEIVER	MAIN	7F01-81FE	7F01-81FF	YES		
		Spotify	RECEIVER	MAIN	7F01-8DF2	7F01-8DF3	YES		
		JUKE *G	RECEIVER	MAIN	7F01-95EA	7F01-95EB	YES		
		Radiko *J	RECEIVER	MAIN	7F01-9AE5	7F01-9AE4	YES		
		Qobuz *BG	RECEIVER	MAIN	7F01-9EE1	7F01-9EE0	YES		
		AirPlay	RECEIVER	MAIN	7F01-91EE	7F01-91EF	YES		
		MC Link	RECEIVER	MAIN	7A-D5AA	7A-D5AB	YES		
VOLUME	MUTE	ON (FULL)	RECEIVER	MAIN	7E-A2	7E-A25C	YES		
		ON (-40dB)	RECEIVER	MAIN	7E-631C	7E-631D	YES		
		ON (-20dB)	RECEIVER	MAIN	7E-DF	7E-DF21	YES		
		OFF	RECEIVER	MAIN	7E-A3	7E-A35D	YES		
PROGRAM	PURE DIRECT	ON	RECEIVER	MAIN	7E-80	7E-807E	YES		
		OFF	RECEIVER	MAIN	7E-82	7E-827C	YES		
	ENHANCER	AUTO	RECEIVER	MAIN	7E-D8	7E-D826	YES		
		OFF	RECEIVER	MAIN	7E-D9	7E-D927	YES		
	TRIGGER	MANUAL ON	RECEIVER	ALL	7E-3F40	7E-3F41	YES		
		MANUAL OFF	RECEIVER	ALL	7E-403F	7E-403E	YES		
MEMORY	VOLUME MEMORY	1	RECEIVER	MAIN	7E-6B	7E-6B95	YES		
		2	RECEIVER	MAIN	7E-6C	7E-6C92	YES		
		3	RECEIVER	MAIN	7E-6D	7E-6D93	YES		
		4	RECEIVER	MAIN	7E-6E	7E-6E90	YES		
		5	RECEIVER	MAIN	7E-6F	7E-6F91	YES		
		6	RECEIVER	MAIN	7E-70	7E-708E	YES		
	VOLUME RECALL	1	RECEIVER	MAIN	7E-75	7E-758B	YES		
		2	RECEIVER	MAIN	7E-76	7E-7688	YES		
		3	RECEIVER	MAIN	7E-77	7E-7789	YES		
		4	RECEIVER	MAIN	7E-78	7E-7886	YES		
		5	RECEIVER	MAIN	7E-79	7E-7987	YES		
		6	RECEIVER	MAIN	7E-7A	7E-7A84	YES		
		OPERATION	PAUSE		RECEIVER	MAIN	7F01-67	7F01-6799	YES
			PLAY		RECEIVER	MAIN	7F01-68	7F01-6896	YES
STOP			RECEIVER	MAIN	7F01-69	7F01-6997	YES		