



Nest Cam Dummy Installation Instructions

(GLOBAL-ENGLISH) June 2021





Nest Cam Wall Mount

Nest Cam Tabletop skip to page 6





Parts & Tools needed Nest Cam Wall Mount








2x Winged Nuts




Installing Nest Cam Wall Mount



Step 1

With the G logo upright, push the wall mount through the corresponding holes in the fixture.

Step 1



Step 2


Step 2

On the other side of the fixture, thread the provided winged nuts onto the stems to secure Nest Cam in place.





Installing Nest Cam Wall Mount



Step 3

Step 3

Attach Nest Cam to the magnetic wall mount and angle the camera down as shown.



Nest Cam Tabletop





Parts & Tools needed

Nest Cam Tabletop




Nest Cam Tabletop




1x Threaded Stem Optional



1x Knurled Nut Optional




Alcohol Wipe
Not included



Phillips Screwdriver Optional, not included



Adhesive




Step 1

If you're installing Nest Cam Tabletop mechanically, skip to page 10.

Step 1

Use an alcohol wipe to clean the surface where Nest Cam will be placed.

Remove the adhesive liner on the bottom of the tabletop stand.



Step 2


Step 2

Hold the tabletop stand so that the security cable is on the right. Place the device in the desired location and apply pressure to the base. Hold for at least 15 seconds.





Adhesive



Step 3

Attach Nest Cam to the base by aligning the pogo pins of the tabletop stand to the bottom of Nest Cam.

Angle Nest Cam so it's upright and facing straight ahead.

Step 4


Run the cable into the fixture. Since Nest Cam is a dummy it does not need to be plugged in to power.

Remove the protective liner from the front of Nest Cam.





Mechanical



Do not remove the adhesive liner when installing Nest Cam mechanically.

Step 1

Use a phillips screwdriver and remove the 2x small screws that are holding the security plate to the bottom of the tabletop stand.



Step 2


Step 2

Insert the threaded rod through the top of the security plate, ensuring it sits flush.






Mechanical



Step 3



Step 3

Re-attach the 2x small screws that were removed in step 1

Step 4

Insert the threaded rod through the fixture and secure underneath using the provided knurled nut.





Mechanical



Step 5

Step 5

Attach Nest Cam to the base by aligning the pogo pins of the tabletop stand to the bottom of Nest Cam.

Angle Nest Cam so it's upright and facing straight ahead.

Step 6

Run the cable into the fixture. Since Nest Cam is a dummy it does not need to be plugged in to power.

Remove the protective liner from the front of Nest Cam.