



Planning the Location




Place the Signature in a partially shaded area

Sources/What to Watch



- Signals can be sent from any source using an HDMI, Component, Ethernet, or digital antenna connection.
- Refer to the operator’s manual for detailed instructions

Weather Proofing



- The Signature is equipped with an HDBaseT receiver in the media bay
 - After all connections are made, all wires must exit the media bay from the bottom.
 - Up to 5 wires can exit the media bay while still maintaining the weatherproof feature.
- Note:** Leave a drip loop as the wires enter the compartment.
- Tighten the thumb screws completely to weatherproof the TV.

SETUP



- Use the TV remote to access the setup menu and run initial installation.
- Select Language, Location and Time Zone, and default TV settings for the TV location.
- Select the corresponding input source and follow on screen instructions to complete setup.
- Refer to the operator's manual for detailed instructions. Press "Menu" on the remote control to access the internal operation manual or visit the product support page on www.snapav.com or www.sunbritetv.com.

CONTROL

The Signature can be controlled via the included remote or universal remote.

IR codes are available at: <https://www.sunbritetv.com/support/product-support/product-faq>.