


Related Products

- WPS-100-NVR-4IP
- WPS-300-NVR-9IP
- WPS-300-NVR-16IP


How to Upgrade

Follow these instructions to upgrade your NVR firmware from the web browser interface.


1. Extract the “.bin” file from the firmware upgrade zip file to a known location on your computer.
2. Open a web browser and navigate to the web interface address of your NVR and log in as an administrator.
3. Click **CONFIG** in the top right corner to navigate to the setup menus.




4. Click **System Update** in the Config menu.



5. Click **Browse** under the Firmware Upgrade section.



6. Select the ".bin" file that was saved to your computer in Step 1 and click **Open**.



7. After the open file window closes, click **Upgrade** to begin the update.



8. Progress will be displayed during the update.



9. After the status bar reaches 100%, close the browser. Then, reopen it and access the NVR again (settings will not be changed during the update). Confirm that the firmware has been updated by visiting the System Update menu and confirming the current firmware version.

The update is now complete.

Contacting Technical Support

Phone: (866.838.5052

Email: techsupport@snapav.com