CRESTRON NVX SETUP

Rev:180309-1400

SINGLE SWITCH SOLUTION

CONTACTING TECH SUPPORT

Phone: 866.838.5052 704.909.5229

Email: TechSupport@SnapAV.com

INFORMATION

- This setup is valid for both the **210** and **310** model lines.
- Switch must be running firmware v1.2.00 or later.

Step 1: Switch Setup

Settings

1. Go to **Advanced > Multicast > IGMP Snooping** and set **IGMP Snooping** settings to **v3**.
2. Set **Unregistered IPMC Forward Action** to **Drop**.

VLAN Settings

3. Go to **Advanced > Multicast > IGMP Snooping** and set **status** to **Enabled**.
4. Set **Fast Leave** to **Enabled**.
5. Set **Querier State** to **Enabled**.
6. Set **Querier Version** to **v3,** then go to the Web interface of the Crestron NVX to complete network settings.



Step 2: NVX Network Settings

IMPORTANT: All instructions to complete setup are not included here. Contact Crestron for complete NVX setup instructions.

1. Click **Network Settings** on the NVX and set a static IP.
2. Set the NVX to **IGMP v3**.